350.001

Features.....1

Outdoor unit.....1

Indoor unit.....2

Wiring diagram.....2

Installation.....3

Operation instruction.....5

Accessories.....5

Warning.....5

2.4GHz WIRELESS DUAL-WAY DIGITAL DOORPHONE




USER MANUAL

Features

- 2.4G wireless digital technique, anti-interference and clear communication.
- Wireless dual-way doorphone. Easy fixing for DIY market.
- Adjustable volume.


Outdoor unit

- Working temperature: -10°C~50°C
- 4X AA bateries
- Dimension 108(W)*157(H)*46(D)mm




Indoor unit

- Working temperature: -10°C~50°C
- Adapter
  Input voltage: AC110-120V/60Hz or 220-240V/50Hz
  Output voltage: AC9V, 300 mA



Wiring diagram



Installation

A.Outdoor unit







① Fasten the rain shade on teh wall.
② Remove the screws on the bottom of outdoor unit and open the panel.






③ Load the batteries.
④ Take down the name plate and then fasten family name or room number .





⑤ Fasten the outdoor unit on the rain shade with screws.
⑥ Cover the panel.





⑦ Fasten the screws on the bottom of the unit.

B.Indoor unit









① Fasten the bracket of indoor unit on the wall.
② Hang the indoor unit on the bracket.
③ Plug the adapter in the power jack or outlet.
④ Plug output pin into the power jack or outlet.

Operation instruction

- From outdoor unit to indoor unit: press the CALL button of outdoor unit, graceful sound from indoor unit will be heard; pick up the handset for talk. Hang up the handset, both indoor unit and outdoor unit will be in standby status,meanwhile the indicator lamp will turn off.
- Adjustable volume.

Accessories

■One indoor unit	■One adapter	■One user manual
■One outdoor unit	■One bracket	■Screws

Warning

- Do not fix the indoor unit near to the wireless telephone.
- Do not fix the indoor unit in a place with high temperature and high humidity.
- Avoid the strong sunshine and heavy rain.
- Do not hit or throw the units
- Do not disassemble the unit without professional guide.
- Please check the indicator lamp for work status.

