

Accessories

Locate Remote Control Switch

Model Ei 159

- Remote Locate capability
- For use with Ei140/Ei150/Ei160RC series Smoke and Heat Alarms
- Quickly locates source of alarm



Product Description

The Ei159 is a switch with Locate functionality, and is intended for installations with interconnected smoke alarms.

The Locate function will stop all the units alarming except those alarms actually sensing smoke, by disabling the interconnect feature for about 10 minutes.

The Locate function will allow the source of the alarm to be quickly located and appropriate action taken, and it can significantly reduce the annoyance to other occupants when false alarms occur at night.

The Ei159 is designed to be used in conjunction with the Ei140, Ei150 and Ei160RC series Smoke and Heat Alarms. (Note: A more suitable accessory for the Ei160RC series is the Ei1529RC remote control switch which provides, test, hush and locate functions)

The Ei159 is supplied complete with its own surface mount pattress and all mounting fixings.

Operation

- Turning on the "Locate" switch will deactivate all interconnected Smoke and Heat Alarms except those actually sensing smoke
- The Ei159 automatically restores the interconnect feature after a period of 10 minutes
- During the 10 minute period, each individual smoke detector will still operate and alarm if it senses smoke
- If the original smoke alarm continues to sound after smoke has cleared, pressing the "Locator" switch again will cancel that alarm

Sparks Electrical Wholesalers Ltd

659-661 Holloway Road, London N19 5SE

Tel: 020 7263 8007

www.sparksdirect.co.uk

Model Ei159


Technical Specification

Supply Voltage:	240V AC	Fixing:	Screw fixings supplied
Battery back up:	No battery back up	Plastic material:	UL94VO flame retardant
Temperature Range:	0 to 40°C	Dimensions:	89mm x 89mm x 47mm
Humidity Range:	0% to 90% Relative Humidity	Weight:	170g
Interconnect:	Up to 12 interconnected Ei141/144/146/151TL/154TL/ 156TL/156TLH/156TLR/161RC/ 164RC/166RC alarms	Warranty:	5 year (limited) warranty

Specifications are subject to change


Installation

Mains Powered Systems



Be very careful about correctly wiring the alarms as mixing Live and Neutral will blow/damage interconnected alarms

9Volt Battery Powered Systems



Use only with
Ei100C/100TYC/100TYCH/103C/105C/105CH/105TYC/3105TYC
Smoke/Heat Alarms

Important Precaution:

Do not install the actual smoke/heat alarm itself in new or renovated buildings until all work is completed (including floor coverings) and the building has been fully cleaned. The wiring can be installed when appropriate. (Excessive dust and debris from building work can contaminate the smoke chamber and cause problems, and it will also invalidate the guarantee). If it must be installed, cover it completely, particularly around the edges, with a dust cover (eg. a plastic bag), until all cleaning is finished.. Connect wires to the unit as in wiring diagram. All wiring must comply with local codes.

Sparks Electrical Wholesalers Ltd

659-661 Holloway Road, London N19 5SE
Tel: 020 7263 8007
www.sparksdirect.co.uk