

6B 5025.a

GB

RCD add-on block (AOB)
for MCB:

- NBNxxxA
- NCNxxxA
- NDNxxxA

User instructions


BD163T, BE163T, BF163T




WARNING : Installation by qualified contractors only


Electrical connection

3Ph + N




3Ph






Mounting MCB + AOB = RCBO

① OFF




②




Open slider

③




④



Ensure the plastic flap is closed before mounting the device into the enclosure

Push strongly to close properly

⑤





Push the grey button to comply with product standard IEC 61009-1 Annex-G.

When button pushed MCB + AOB = RCBO (slider is locked)


Mounting into panelboard

WARNING: Disconnect wires before any insulation test, stick the label with the red indication on the side of the panelboard








Test




Press test button :
RCBO must trip









For removal of AOB from MCB, insert screwdriver, push grey lock button up.

This allows slider to be open again. The AOB remains usable.

GB Warranty NOT APPLICABLE FOR AUSTRALIA

A warranty period of 24 months is offered on hager products, from date of manufacture, relating to any material of manufacturing defect. If any product is found to be defective it must be returned via the installer and supplier (wholesaler). The warranty is withdrawn if:

- after inspection by hager quality control dept the device is found to have been installed in a manner which is contrary to IEE wiring regulations and accepted practice within the industry at the time of installation.
- The procedure for the return of goods has not been followed. Explanation of defect must be included when returning goods.

Hager 11.2012 OCOM 115161