

GUIDE TO LED WIRING

Iw 350mA LED Products


3w 700mA LED Products

Drivers

Connectors

Transformers

Iw LED PRODUCTS




Iw 350mA products in the Astro range include:


Fosso Recess (0629, 0631 and 0757) Tango (0825, 0826, 0831, 0832 and 0833)

3w LED PRODUCTS

One 3w 700mA LED product can be wired to our 3w 700mA Constant Current LED Driver (1271).



Single 3w 700mA LED product connected to a 3w 700mA LED Driver



3w 700mA products in the Astro range include:

Ice LED (5579 and 5580) Mint LED (5581 and 5582) Beam (0937, 0938 and 0939) Terra 42 (0936)

DRIVERS

A driver reduces the voltage supplied to the LED and "drives" either a **constant voltage** or a **constant current** to the LED.

It is very important that LED products which do not have a built-in driver must be connected to an LED driver, not directly to the mains.


Connecting LEDs directly to mains will cause irreparable damage to the product.

It is very important that the power is disconnected until installation of the LED products is completely finished. Any connections made with the power on will cause irreparable damage to the product.

Some, but not all, of our drivers are IP65 rated. The installer must therefore ensure that IP integrity is maintained, either by positioning the driver indoors or using waterproof junction boxes.


All our LED products that need a separate driver must be wired in SERIES not parallel.

SERIES WIRING DIAGRAM





PARALLEL WIRING DIAGRAM





CONNECTORS

Below is the diagram we use on our instructions showing a series circuit including the connectors that we sell.

These connectors are specifically for LED circuits and are gel filled to provide IP65 protection when used outside.

