## :hager



#### (GB) Design 10 Two Row Consumer Unit

Instructions/Data Sheet

This Consumer Unit and Hager devices conform with the following standards: Consumer Unit: BS EN 61439-3 including Annex ZB. Switch-disconnectors: BS EN 60947-3. Residual Current Circuit Breaker (RCCB): BS EN 61008-1 Residual current operated circuit breaker with integral overload (RCBO): BS EN 61009-1 Miniature Circuit Breaker (MCB): BS EN 60898-1

#### Installation Instructions:

ZD0829

All product(s) must be installed by a suitably competent electrician Giving consideration to their intended use and in accordance with the current edition of BS 7671 (IET Wiring Regulations).


The Electricity at Work regulations and the Health and Safety at Work Act shall be complied with.

Only equipment and arrangements specified in Hager's technical documentation / catalogue shall be used.


Install in the horizontal plane only.

#### Important notice:


To prevent potential overheating from loose connections the installer shall check connections are tight to the torque levels stated in these instructions prior to energizing this board. This check should include factory made connections which may have loosened in transit.



Lift door and loosen the two captive screws until the cover can be removed.



These metal units are provided with knockouts suitable for use with 100x50mm trunking, 50x50mm trunking, 40x25mm trunking and also large rear knockouts. Grommet strip is provide to protect the cables when entering the board.




- 1.0mm<sup>2</sup> to 16mm<sup>2</sup> for outgoing cables
- ZD0829 up to 35.0mm<sup>2</sup> for incoming live cables


Single conductors below 1.5mm<sup>2</sup> need to be doubled back in the terminal bar

Additional Extras							
Accessory	Ref.						
Cable protector plate Can be used on the rear knockouts to smooth any sharp edges	Insulated: VM02CE Metal: VM01CE						
<b>Cable Clamp</b> Can be used to clamp meter tails in place when entering main switch	VA10MT						

Good workmanship and proper materials must be applied by the installer. The cable entry method shall, as far as reasonably practical, maintain the non-combustable arrangement of the enclosure. Account shall be taken of these instructions.



The units have multiple fixing points that will suit No.8 & No.10 screws



Rear cable entries shall enter thorough selected rear Knockout; once the Knockout is removed apply the grommet strip provided. Grommet strip lengths: Small EKO - 79mm, Large EKO - 127mm Rear EKO - 255mm

#### **Guidance Notes:**

The total load must not exceed the rating of the incoming device or the assigned assembly rating (InA) whichever is the lower. Each neutral and earth connection must correspond numerically to its outgoing way. Additional blanks (ref. JK01B) are available to cover spare ways.

A pack is provided to label this consumer unit, please consult us for spares or replacements. Operating Instruction leaflet is provided overleaf. This leaflet should be left for the end user. Single conductors below 1.5mm<sup>2</sup> need to be doubled back in the terminal bar. Consumer Units incorporating RCDs in TT systems should incorporate an S type (time Delayed) RCCB, e.g. 100 mA s-type RCCB . Alternatively a main switch with RCBO protection on all outgoing circuits should be used. Precautions need to be taken to prevent faults to earth on the supply side of the RCD (as per BS7671 regulation 531.4.1)

### ZD0829 Cable Access:


Cable access into the metal consumer unit must maintain the integrity of the non-combustable consumer unit so far as reasonably practicable. This can generally be achieved by the installer ensuring that cable access holes they make in the enclosure do not to leave gaps greater than:

· 1.0 mm for the horizontal top surface and

· 2.5 mm for all other surfaces of the enclosure that are accessible after installation.

For rear cable access, the minimum number of knockout(s) shall be removed.

Tests on Hager consumer units have indicated that there is no specific need for fire rated cable glands or intumescent sealing in addition to the guidance below, with respect to achieving a non-combustible enclosure. However, this does not preclude the designer / installer using fire rated cable glands or intumescent sealing or other methods, should they consider necessary.



#### Fitting Hager MCBs and RCBOs:

Only equipment and arrangements specified in Hager's technical documentation / catalogue shall be used.

- 1. Isolate the electrical supply from the consumer unit.
- 2. Remove the front cover, by loosening the two captive screws.
- 3. Fully slacken the lower terminal of the device.
- 4. Fully open the bottom device clip (fig 1.)

- 5. Locate the device onto the din rail, and busbar. Ensure that the busbar tooth is within the device terminal cage.
- Close the bottom device clip.
- 7. While holding the device firmly onto the busbar, fully tighten the lower terminal screw.
- 8. After fitting all outgoing devices and connecting all outgoing cables, please check the tightness of all cable connections. This should include all factory made connections, which may have loosened during installation or transit.

#### Warranty

This distribution board is offered with a 24 month warranty against defective material or manufacture. If a warranty claim is necessary, please call the technical support number given at the bottom of the page and we will be pleased to help.

fig

For dimensional information and weights please consult the Hager catalogue.

Hager Technical Help Line: 01952 675 689 Hager Technical Fax: 01952 675 557 Hager Technical E-mail: technical@hager.co.uk

Website: www.hager.co.uk

# :hager


			Cables	>1.5mm²	I.5mm <sup>2</sup> Cables ≤1.5mm <sup>2</sup>			
Torque Settings			Tightening	Tightening torque (N.m)		torque (N.m)	Cable Stripping (mm)	
0	Pz No.	(mm)	Single Cable	Multi Cables	Single Cable	Multi Cable		
Consumer unit terminals	2	6.5	2	2	1.5	1.5	10	
	2	0.5	2	2	1.5	1.5	10	
B switch disconnectors	2	6.5	3.6	3.6	3.6	3.6	15	
Circuit protection		0.0	0.0	0.0	0.0	0.0	10	
/TN MCB	2	6.5	2.8	2.8	2.8	2.8	13	
IBN/NCN/NDN MCB	2	6.5	2.8	2.8	2.8	2.8	13	
RCBO	2	5.5	2.1	2.1	2.1	2.1	13	
RCCB	2	5.5	2.8	2.8	2.8	2.8	13	
nterface characteristics								
Rated & operational voltage (Un	(110)							
230V a.c. 50Hz	/ Uej							
Rated insulation voltage (Ui) 320V a.c. 50Hz								
Rated impulse withstand voltage lkV	e (Uimp)							
Rated current of the Assembly (I	nA)							
Note: Dependent upon rating of m	ain incom	ing devid	e					
Rated current of an Outgoing circuit (Inc) Rated current of outgoing unit (Inc)   MCB 6A - 63A (marked rated current on device) RCCB 40A -100A (marked rated current on device)   RCB0 6A - 50A (marked rated current on device) RCCB 40A -100A (marked rated current on device)								
Rated conditional short-circuit c Annex ZB: 16 kA rms at 250V, pow			• •	arrangements s	pecified in Hage	r's technical doc	cumentation /	
catalogue. Protection against electric shoc	le .							
Consumer unit shall be installed in		ical syste	em conforming t	o the current ed	ition of IEC 603	64 / BS 7671		
Rated diversity factor (RDF) / Va	lues of as	ssumed	loading	Note: RDF o	nly applies to co	ontinuously and	simultaneously loaded	
lway = 1.0			-	circuits.		-		
2way – 3way = 0.8 4way – 5way = 0.7				In principle t	his means adiac	ent circuit-brea	kers having a load	
way – 9way = 0.6 'on' time exceeding 30 minutes or where a load not exceed								
Oway and above = 0.5 minutes has an 'off' time less than the 'on' time, will need to the rated diversity factor applied as indicated.								
				the rated dive	ersity factor app	lied as indicated	1.	
Rated frequency (fn) 50 Hz								
Pollution degree								
Types of system earthing for whith TNC-S, TN-S when installed in an Hager recommends for TT system:	electrical	installat	ion complying w		itch with BCBO	protection only	on all outgoing circuits	
ndoor use only		71-2-41				,		
Stationary ASSEMBLY								
Degree of protection P2XC with Door Open / closed an Note: Where cables are installed th								
ntended use ntended for use in domestic (resic	<u> </u>							
Electromagnetic compatibility (E	,							
External design /ML: Wall-mounted, surface type,	enclosed	assemb	y.					
<b>Mechanical impact protection</b> K 05								


IK 05


The type of construction Fixed parts

Type A DBO (Distribution board for use by ordinary persons)

:hager







Design 10

С

D

Dimensions	Enclosure Size							
(mm)	2	3	4	5	6	7		
A	155	227	299	370	406	478		
В	486	486	486	486	486	486		
С	83	83	83	83	83	83		
D	100	100	100	100	100	100		