


PUBLB、PUBLBLK、PUBLSC



## INSTALLATION INSTRUCTIONS

**IT IS RECOMMENDED THAT THIS LUMINAIRE IS INSTALLED BY A QUALIFIED ELECTRICIAN  
ENSURE THAT ALL THE ELECTRICITY IS SWITCHED OFF AT THE MAINS SUPPLY BEFORE INSTALLING O  
MAINTAINING THIS LUMINAIRE**

### **WARNING-THIS LUMINAIRE SHOULD BE EARTHED**

**MARK THE POSITION OF THE FIXINGS ON THE WALL AVOIDING THE WIRING IN THE WALL  
DRILL AND PREPARE THE HOLES FOR THE SCREWS (NOT SUPPLIED) ENSURING THAT THE FIXINGS ARE  
INTO SOLID MATERIAL AND USING RAWL-PLUGS IF NECESSARY.DO NOT PUT SCREWS DIRECTLY INTO  
PLASTERBOARD (USE APPROPRIATE FITTINGS).**

**TAKE CARE TO SUPPORT LUMINAIRE TO PREVENT STRAIN BEING PLACED ON ANY WIRING**

**PREPARE SUPPLY CABLE AS FOLLOWS:CAREFULLY REMOVE OUTER COVERING FOR A DISTANCE OF  
APPROX.150m.,REMOVE 6mm OF INSULATION FROM THE RED AND BLACK WIRES .FIT GREEN/YELLOW  
P.V.C.SLEEVING TO EARTH WIRE**

**CONNECT THE WIRES TO LUMINAIRE USING A 240 VOLT 3AMP WAY TERMINAL BLOCK COMPLYING TO 1  
REGULATIONS OF EN60998-2-1 OR EN60998-2-2 AS FOLLOWS:CONNECT THE  
LIVE SUPPLY (RED OR BROWN) WIRE TO THE BROWN LEAD ON THE LUMINAIRE**

**CONNECT THE NEUTRAL SUPPLY (BLACK OR BLUE) WIRE TO THE BLUE LEAD ON THE LUMINAIRE.  
CONNECT THE EARTH SUPPLY(GREEN/YELLOW)TO THE GREEN/YELLOW LEAD ON THE LUMINAIRE.WHEN  
CARRYING OUT THIS PROCEDURE ENSURE ALL THE TERMINAL SCREWS ARE FULLY TIGHTENED AND THAT  
NO LOOSE STRANDS OF WIRE ARE LEFT OUT OF CONNECTIONS .NOW INSULATE THE TERMINAL BLOCK BY  
WRAPPING TWO LAYERS OF GOOD QUALITY INSULATING TAPE COMPLETELY AROUND IT LEAVING NO  
SURFACES UNCOVERED.**

**SECURE THE LUMINAIRE TO THE WALL USING APPROPRIATE FIXINGS.TAKE CARE NOT TO DAMAGE OR  
TRAP ANY OF THE WIRING OR LEAVE ANYWIRES EXPOSED.**

**NEVER EXCEED WATTAGE SHOWN ON LUMINAIRE  
TERMINAL BLOCK NOT INCLUDED.(INSTALLATION MAY REQUIRE ADVICE FROM A QUALIFIED ELECTRICIAN.)**

**LOCK WALL PLATE ONTO ARM IN REQUIRED PLACE AND FIX TO WALL ENSURING YOU DO NOT ROTATE  
FITTING MORE THAN 10° IN EITHER DIRECTION**

**UNDER NO CIRCUMSTANCES SHOULD  
THE FITTING BE INSTALLED WITH THE  
OPEN SIDE OF THE HOOD FACING UP**

